


Choosing the right firmware

Example: 1_75mm-RAMBo13a-E3Dv6lite.hex



Filament types:

Determines what type of filament is your printer using.

There are two options:

- **1_75mm_MK2** represents 1.75mm filament (**latest and in use on MK2**)
- **1_75mm** represents 1.75mm filament ("MK1" only)
- **3mm** represents 3mm filament (no longer used)

Electronic types:

RAMBo 1.3a

RAMBo13a

Latest, LCD adapter is integrated



RAMBo 1.0a

RAMBo10a

Obsolete, no longer ships, LCD headers not populated or LCD adapter sticking out



Hotend types:

Determines what type of hotend is your printer using.

There are three options:

- **E3Dv6lite** represents E3D v6Lite hotend ("MK1" only)
- **E3Dv6full** represents E3D v6full hotend (**latest on MK2** or user upgraded on the "MK1")
- **PrusaNmk2** represents Prusa Nozzle MK2 hotend for 3mm filament (no longer used)